



# Einhell

# EXPERT

## POWER X-CHANGE

Cordless Chain Saw

**FORTEXXA 18/30**

Item No.: 4600010

Ident No.: 21010

Bar Code: 4006825656572

The Einhell FORTEXXA 18/30 cordless chainsaw is a member of the Power X-Change family. The chainsaw is powered by a brushless electric motor from Einhell, is equipped with a high-quality OREGON rail and chain and has a tool-less chain tensioning/changing facility. For safety there is chain catch and kickback protection with instant-reaction chain brake, and for maintenance there is automatic chain lubrication via the large oil filler opening. The claw stop is made of metal and the ergonomic handle has a soft grip. The chain speed can be adjusted according to the application; it can be switched between full power and Eco mode. This product comes without a battery or charger.

## Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Einhell Brushless Motor
- High-quality chain and bar from OREGON
- Selection of HIGH power (8.9 m/s) and ECO power (6 m/s)
- Speed setting depending on the application
- Toolless chain tensioning and changing
- Kickback protection with instant chain brake
- Ergonomic handle with Softgrip
- Sturdy stop claws made of metal
- Big filler opening
- Automatic chain lubrication
- Chain catcher
- Supplied without battery and charger (available separately)
- Recommendation for optimum results: 4.0 Ah rechargeable battery



## Technical Data

- Sword length 300 mm
- Max. cutting length 27 cm
- Chain cutting speed 8.9 m/s
- Oil tank capacity 160 mL

## Logistic Data

- Product weight (kg) 4.1 kg
- Gross weight (kg) 5 kg
- Dimensions single packaging 257 x 481 x 282 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 20 kg
- Dimensions Export Carton 614 x 487 x 475 mm
- Container quantity (20"/40"/40"HC) 656 | 1376 | 1720



## Available as special accessories



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 2  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



Ersatzkette 30cm 1,1 45T 3/8  
Chain Saw Accessory  
Item No.: 4500192  
Bar Code: 4006825663532  
Einhell Accessory



2x 3,0Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512083  
Bar Code: 4006825638509  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 2,5Ah Power X-Change  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



18V 3,0 Ah Power-X-Change  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB  
Battery  
Item No.: 4511524  
Bar Code: 4006825656206  
Einhell Accessory





18V 4,0Ah PXC Starter Kit 2  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 4,0Ah Power X-Change 2  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory

# Battery-Running-Times

One Battery for All		
	sawing <sup>1</sup> (pieces)	sawing <sup>2</sup> (pieces)
1.5 Ah	53	59
2.0 Ah	70	78
2.5 Ah	88	98
3.0 Ah	105	117
4.0 Ah	140	156
5.2 Ah	182	203
6.0 Ah	210	234

For best performance select a battery with at least 4.0 Ah

**Test setup:**

- 1) scantling 70x70 mm - BOOST
- 2) scantling 70x70 mm - ECO